

Univerza v Ljubljani

A proximity focusing RICH with time-of-flight capabilities

Peter Križan

University of Ljubljana and J. Stefan Institute

For the Belle Aerogel RICH R&D group

10th Topical Seminar on Innovative Particle and Radiation Detectors
(IPRD06) 1 - 5 October 2006 Siena, Italy



Contents

Introduction, motivation and requirements

Radiator with multiple refractive indices

Time-of-flight measurement with a RICH

Beam tests

Summary



Belle @ KEK-B in Tsukuba



Tsukuba-san

KEKB

Belle

~diameter 1 km


October 4, 2006

IPRD06, Siena

Peter Križan, Ljubljana




Belle spectrometer at KEK-B



Accumulated data sample **>600 M BB-pairs**



PID upgrade in the endcap



improve K/π separation in the forward (high mom.) region for few-body decays of B mesons

good K/π separation for $b \rightarrow d\gamma$, $b \rightarrow s\gamma$

improve purity in fully reconstructed B decays

low momentum ($<1\text{GeV}/c$) $e/\mu/\pi$ separation ($B \rightarrow K\ell\ell$)

keep high the efficiency for tagging kaons



BELLE Aerogel RICH group

I. Adachi, I. Bertović, S. Fratina, K. Fujita, T. Fukushima, A. Gorišek,
D. Hayashi, T. Iijima, H. Kawai, M. Konishi, S. Korpar, Y. Kozakai,
P. Križan, A. Kuratani, Y. Mazuka, T. Nakagawa, S. Nishida,
S. Ogawa, S. Ohtake, R. Pestotnik, S. Saitoh, T. Seki, A. Stanovnik,
T. Sumiyoshi, Y. Uchida, Y. Unno

Chiba University, Japan

Toho University, Funabashi, Japan

High Energy Accelerator Research Organization (KEK), Japan

J. Stefan Institute, Ljubljana, Slovenia


University of Ljubljana, Slovenia

Nagoya University, Nagoya, Japan

Tokyo Metropolitan University



Proximity focusing RICH in the forward region



K/ π separation at 4 GeV/c
 $\theta_c(\pi) \sim 308$ mrad ($n = 1.05$)
 $\theta_c(\pi) - \theta_c(K) \sim 23$ mrad

$d\theta_c(\text{meas.}) = \sigma_0 \sim 13$ mrad
With 20mm thick aerogel and
6mm PMT pad size

→ 6σ separation with $N_{pe} \sim 10$




Beam test: Cherenkov angle resolution and number of photons

Beam test results with 2cm thick aerogel tiles:

excellent, $>4\sigma$ K/ π separation


NIM A521(2004)367



but: Number of photons has to be increased. \rightarrow






How to increase the number of photons?



What is the optimal radiator thickness?

Use beam test data on σ_0 and N_{pe}



Minimize the error per track: $\sigma_{track} = \frac{\sigma_0}{\sqrt{N_{pe}}}$

October 4, 2006


Optimum is close to 2 cm



Radiator with multiple refractive indices


How to increase the number of photons without degrading the resolution?

measure overlapping rings
→ "focusing" configuration






Beam tests




Photon detector: array of 16 H8500 PMTs

October 4, 2006

IPRD06,



Clear rings, little background











Focusing configuration

NIM A565 (2006) 457

4cm aerogel single index



2+2cm aerogel




October 4, 2006



Focusing configuration – $n_2 - n_1$ variation





- upstream aerogel: $d=11\text{mm}$, $n=1.045$
- downstream aerogel layer: vary refractive index
- measured resolution in good agreement with prediction
- wide minimum allows some tolerance in aerogel production

NIM A565 (2006) 457





Multilayer extensions



- Multiple layer radiators combined from 5mm and 10mm tiles
- obtained Cherenkov angle resolution per track is around 4.3 mrad


→ π/K separation at 4 GeV better than 5σ



Photon detector: H(A)PD


Multialkali photocathode

-10kV
15~25mm




Pixel PD or APD

- 12 x 12 channels
- 65% effective area (59mm x 59mm)



- tests with single channel and 3x3 channel device look promising



- 12 x 12 channel version: problems with sealing and activation

R&D project in collaboration with HPK







Photon detector: MCP-PMT

BURLE 85011 MCP-PMT:

- multi-anode PMT with two MCP steps
- 25 μm pores
- bialkali photocathode
- gain $\sim 0.6 \times 10^6$
- collection efficiency $\sim 60\%$
- box dimensions $\sim 71\text{mm}$ square
- 64(8x8) anode pads
- pitch $\sim 6.45\text{mm}$, gap $\sim 0.5\text{mm}$
- active area fraction $\sim 52\%$



- Tested in combination with multi-anode PMTs

- $\sigma_g \sim 13 \text{ mrad}$ (single cluster)
- number of clusters per track $N \sim 4.5$
- $\sigma_g \sim 6 \text{ mrad}$ (per track)
- $\rightarrow \sim 4 \sigma \pi/K$ separation at 4 GeV/c

- 10 μm pores required for 1.5T
- collection eff. and active area fraction should be improved
- aging study should be carried out





TOF capability

With the use of a fast photon detector, a proximity focusing RICH counter can be used also as a **time-of-flight counter**.

Cherenkov photons from two sources can be used:

- photons emitted in the aerogel radiator
- photons emitted in the PMT window





Beam tests: study timing properties of such a configuration. →



TOF capability: photons from the ring

- obtained time resolution for Cherenkov photons from the aerogel radiator is **50ps**, and agrees well with the value from the bench tests
- resolution for full ring (~ 10 photons) would be around **20 ps**





- distribution of hits on the MCP-PMT (13 channels were instrumented) - left
- corrected distribution using the tracking information - left




TOF capability: window photons

- expected number of detected Cherenkov photons emitted in the PMT window (2mm) is ~ 15
- expected resolution ~ 35 ps \rightarrow



- TOF test with pions and protons at 2 GeV/c
- distance between start counter and MCP-PMT is 65cm






Time-of-flight with photons from the PMT window

Benefits: Čerenkov threshold in glass (or quartz) is much lower than in aerogel.

Aerogel: kaons (protons) have **no** signal below 1.6 GeV (3.1 GeV): identification in the **veto** mode.




Window: threshold for kaons (protons) is at ~ 0.5 GeV (~ 0.9 GeV): \rightarrow **positive identification** possible.



Time-of-flight with photons from the PMT window - 2

Window: threshold for kaons (protons) is at ~ 0.5 GeV (~ 0.9 GeV): \rightarrow **positive identification** possible below threshold in aerogel.

Also: **pion** PID becomes more **reliable** around the **pion** threshold in aerogel (~ 0.5 GeV)



Threshold in the **window**: π K p



Summary

- A proximity focusing RICH with ~ 20 cm radiator to photon detector distance and $\sim 6 \times 6 \text{ mm}^2$ pads is being developed for the upgrade of the Belle forward PID.
- Single refractive index radiator has an optimal radiator thickness of ~ 2 cm; increasing the thickness results in degradation of Cherenkov angle resolution per track.
- Way out: use of multi layer radiator with varying refractive index
- Expected performance of the focusing configuration: excellent p/K separation up to 4 GeV/c
- More studies are needed to decide which radiator configuration and photon detector we should use for the Belle PID upgrade
- Such a counter can also be used for TOF measurement
→ extend PID capabilities into low momentum region