RICH with multiple aerogel layers of different refractive index

Samo Korpar University of Maribor and Jožef Stefan Institute, Ljubljana

November 30 - December 5, 2004 RICH2004

I. Adachi, S. Fratina, T. Fukushima, A. Gorišek, T. Iijima, H. Kawai, M. Konishi, Y. Kozakai, P. Križan, T. Matsumoto, S. Nishida, S. Ogawa, S. Ohtake, R. Pestotnik, S. Saitoh, T. Seki, A. Stanovnik, T. Sumiyoshi, Y. Uchida, Y. Unno, S. Yamamoto

- Belle PID upgrade requirements
- beam test setup
- limitation of proximity focusing aerogel RICH
- dual refractive index configurations concept
- tests of different configurations
- summary



Belle PID UPGRADE

requirement: ~ 4σ K/ π separation @ 1-4 GeV/c

 proximity focusing aerogel RICH in forward direction





- n ~ 1.05
- $\vartheta_{c}(\pi) = 310 \text{ mrad } @ 4 \text{ GeV/c}$
- $\vartheta_{c}(\pi) \vartheta_{c}(K) = 23 \text{ mrad } @ 4 \text{ GeV/c}$
- pion threshold 0.44 GeV/c
- distance from aerogel entrance window to photon detector 200 mm
- track incidence angles ~ 17° 34°



BEAM TESTS

At KEK-PS

- march 2004 $\pi 2$ (0.5-4 GeV/c)
- june 2004 T1 (0.5-2 GeV/c)

Photon detector

- 4x4 array Hamamatsu H8500
- 1024 channels
- 52.5 mm pitch (84% eff. area)
- two MWPCs for tracking
- different aerogel configurations¹
 tested







SINGLE PHOTON CHERENKOV ANGLE RESOLUTION

Two main contributions to single photon resolution (n=1.05, d=1cm)

pad size a (~6mm)

$$\sigma_a = \frac{\cos^2 \vartheta_c a}{\sqrt{12} \left(l - \frac{1}{2} d \right)} \approx 8 m r a d$$

aerogel thickness d

$$\sigma_d = \frac{\cos \vartheta_c \sin \vartheta_c d}{\sqrt{12}(l - \frac{1}{2}d)} \approx \frac{4mrad}{cm} d$$

$$\sigma_{\vartheta_c}^2 \approx \sigma_a^2 + (Ad)^2$$



RICH with multiple aerogel layers of different refractive index (slide 4)



OPTIMAL AEROGEL THICKNESS

Single track Cherenkov angle resolution

$$\sigma_{track} = \frac{\sigma_{\theta_c}}{\sqrt{N}}$$

with no attenuation (N=Bd)



minimum at

$$d_{min} = \frac{\sigma_a}{A} \approx 2cm$$

• minimum sigma (data) $\sigma_{track} \approx \frac{14 \, mrad}{\sqrt{6}} = 5.7 mrad$



November 30 - December 5, 2004 RICH2004 RICH with multiple aerogel layers of different refractive index (slide 5)



DUAL REFRACTIVE INDEX CONFIGURATIONS

How to increase number of photons without degrading the resolution?



measure two separate rings
 "defocusing" configuration



measure overlapped rings "focusing" configuration







November 30 - December 5, 2004 RICH2004 RICH with multiple aerogel layers of different refractive index (slide 7)



DEFOCUSING CONFIGURATION @ 3 GeV/c, data







RICH with multiple aerogel layers of different refractive index (slide 8)

0

0.2



0.4

tx(rad)





FOCUSING CONFIGURATION - data



November 30 - December 5, 2004 RICH2004 RICH with multiple aerogel layers of different refractive index (slide 10)



FOCUSING CONFIGURATION - low momentum

overlapping of rings for low momentum tracks



Good overlapping down to 0.6 GeV/c

November 30 - December 5, 2004 RICH2004





FOCUSING CONFIGURATION - momentum scan, data

 number of detected hits as function of momentum

single photon resolution as function of momentum







FOCUSING CONFIGURATION - different incidence angles

overlapping of rings for inclined tracks

• expected range ~ 17°-34°



Good overlapping up to 30°

November 30 - December 5, 2004 RICH2004 RICH with multiple aerogel layers of different refractive index (slide 13)



FOCUSING CONFIGURATION - inclined tracks, data

- 2+2cm aerogel
 MD-6,9,4,5
 RUN 210
- angle 20°

- 2+2cm aerogel
- MD-6,9,4,5
- RUN 216
- angle 30°







RICH with multiple aerogel layers of different refractive index (slide 15)



PID CAPABILITY: LIKELIHOOD CALCULATION

 distribution of Cherenkov photons from both radiators and uniform background can be approximated by

$$n_{cf}(\vartheta, \varphi, m) \approx \frac{1}{2\pi} \left(\frac{1}{\sqrt{2\pi}\sigma_1} e^{-\frac{(\vartheta - \vartheta_1(m))^2}{2\sigma_1^2}} + \frac{1}{\sqrt{2\pi}\sigma_2} e^{-\frac{(\vartheta - \vartheta_2(m))^2}{2\sigma_2^2}} \right)$$

$$n_{bf}(\vartheta, \varphi, m) \propto \vartheta$$

likelihood function

$$L(m) = \prod_{no \ hit \ i} e^{-\bar{n}_i(m)} \prod_{hit \ i} (1 - e^{-\bar{n}_i(m)})$$

$$\ln L(m) = -\sum_{no \ hit \ i} \bar{n}_i(m) + \sum_{hit \ i} \ln (1 - e^{-\bar{n}_i(m)}) =$$

$$= -\bar{N}(m) + \sum_{hit \ i} (\bar{n}_i(m) + \ln (1 - e^{-\bar{n}_i(m)}))$$

average number of photons is needed only for pixels with hit



PID CAPABILITY - MC results, focusing configuration

distribution of log likelihood difference for pions and kaons

 kaon efficiency as a function of momentum at 5% pion fake rate



November 30 - December 5, 2004 RICH2004 RICH with multiple aerogel layers of different refractive index (slide 17)



SUMMARY

• A proximity focusing RICH with ~ 20 cm radiator to photon detector distance has an optimal radiator thickness of ~ 2 cm, increasing the thickness results in degradation of Cherenkov angle resolution per track.

- Way out: use of multi layer radiator with varying refractive index
- We have tested both configurations, dual and multiple radiators
- Results are very promising
- More studies are needed to decide which configuration we should use for the Belle PID upgrade





BACKUP SLIDES



RESOLUTION: simple model

overlapping of two uniform distributions



RICH with multiple aerogel layers of different refractive index (slide 20)







AEROGEL SAMPLES



- Novosibirsk
- Matsushita(2002,Methyl-alcohol)
- Matsushita(2002,DMF)
- Chiba(2003)
- Matsushita(2001)

Aerogels with high transmission length (~40mm) and index of n =1.05 are now available.

already tested at 2001 beam test

Aerogels with up to n=1.07 have been produced.





- Two layers are chemically attached in one sample.
- Two layers have different indices.
- Easy to handle in the construction.
- Less sensitive to surface effect.



- Two Cherenkov rings are observed.
- Low photon yield (due to worse transmission length)
- Performance should be studied in future (e.g. comparison with separate radiators).





November 30 - December 5, 2004 RICH2004

RICH with multiple aerogel layers of different refractive index (slide 24)



FOCUSING CONFIGURATION: angle, different parts of ring

- 2+2cm aerogelMD-6,9,4,5
- RUN 210
- angle 20°





FOCUSING CONFIGURATION @ 3 GeV/c, data









MULTILAYER FOCUSING COMBINATION - data



RICH with multiple aerogel layers of different refractive index (slide 27)

