


# Use of Sealed Radioactive Sources for Teaching Purpose in Schools



## CONTENTS

	<u>PAGE</u>
Notes on "Code of Practice on the Use of Sealed Radioactive Sources for teaching Purposes in Schools"	1 - 3
Appendix 1. Code of Practice On The Use of Sealed Radioactive Sources For Teaching Purposes In Schools	4 - 8
2. Procedures of checking the efficiency and condition of the GM tube and scaler	9 - 12
3. Procedures of performing "Wipe Test"	13 - 22
4. Sample record form for storage of radioactive sources	23 - 25
5. Specifications for storage cupboard	26
6. Specifications for the radioactive source lifting tool	27



Science Section  
Education Department

## Notes on "Code of Practice on the Use of Sealed Radioactive Sources for Teaching Purposes in Schools"

This article should be read in conjunction with the above mentioned Code of Practice (Appendix 1). The aim is to illustrate how SI units are converted from the traditional units and how routine checks can be carried out at intervals not exceeding 6 months under the supervision of the radioactive source custodian. Specifications of the storage cupboard and the radioactive source lifting tool, and samples of the record form for storage of radioactive sources are also included.

### (A) SI unit of radioactivity measured : becquerel

In expressing the activity of a radioactive source, the traditional unit is the curie (Ci), defined as 1 curie =  $3.7 \times 10^{10}$  disintegration per second.

The SI unit of radioactivity measured is the becquerel (Bq) and

$$1 \text{ Bq} = 1 \text{ disintegration per second.}$$

For conversion,  $1 \text{ Ci} = 3.7 \times 10^{10} \text{ Bq}$

$$1 \mu\text{Ci} = 3.7 \times 10^4 \text{ Bq}$$

or  $1 \mu\text{Ci} = 37 \text{ kBq}$

The commonly available sources in the school Physics laboratory have an activity of 5  $\mu\text{Ci}$ .

Thus  $5 \mu\text{Ci} = 5 \times 37 \text{ kBq}$   
 $= 185 \text{ kBq}$

To make an approximation for easy reference, the Radiation Board has recommended the following conversions :

<u>Original Activity</u>	<u>Revised Activity</u>
0.002 $\mu\text{Ci}$	75 Bq
0.02 $\mu\text{Ci}$	750 Bq
0.125 $\mu\text{Ci}$	5 kBq
5 $\mu\text{Ci}$	200 kBq
9 $\mu\text{Ci}$	350 kBq

### (B) Routine checks of monitoring instruments

The common monitoring instrument possessed by the school Physics laboratory consists of a G-M tube (GM tube) connected to a scaler. The Mullard type ZP1481 (MX 168) GM tube, a halogen-quenched tube sensitive to  $\beta$  - and  $\gamma$  - radiation and high energy  $\alpha$  - particle is recommended as a general purpose radioactive detecting tube in the *List of Standard Physics Furniture & Equipment for Physics (S4-5)*. The tube has a robust body with a thin mica end window fitted with a removable protective open mesh plastic cap. The construction of the tube determines its high sensitivity to  $\beta$  - radiation.

For schools in possession of the PANAX Radioactivity Demonstration Kit Type SK 107B, the source custodian may find the accompanied manual entitled "A Basic Course of Radioisotope Experiments" very useful. This booklet was written by Dr. F. H. Kendall (formerly, the Director of the Radioisotope Unit, University of Hong Kong). Experiment 2 (pp 18-20) of the booklet on "Characteristic Curve of the GM Counter" may serve as a convenient method to check the efficiency and condition of the GM tube and scaler.

As an alternative, the custodian may follow the working schedule (in the form of a worksheet) as shown in Appendix 2. Results of a typical experiment are entered into the worksheet for teachers' reference.

The graph of count-rate against applied voltage is called the characteristics curve of the GM tube. *The length and slope of the plateau are criteria used to assess the efficiency and condition of the tube.*

For normal counting purposes, the working voltage  $V_w$  is usually set at a value about 50 V higher than the threshold voltage ( $V_w = V_T + 50$  V). At the working voltage, small fluctuations in the applied voltage will not cause significant deviations in count-rate. In routine checks of sources, the GM tube should be set at the working voltage found in this experiment.

### **(C) "Wipe Test"**

Routine checks on the sealed radioactive sources are mainly tests for leakage or surface contamination of such sources. The "Wipe Test" is the recommended test for sources available in the school Physics laboratory. The entire external surface of the sealed source should be wiped with material (e.g. swab, tissue or cotton bud) moistened with a liquid which is effective in removing the radioactive material involved. The liquid should not attack the container or any bonding material. Ethanol or water was recommended in the code of practice. *The radioactivity removed is measured and its value should be less than 200 Bq.* In this case the source may be considered to be free from leakage. Otherwise, any source failing the routine checks should be considered as defective. Such sources should be withdrawn from use.

The working schedule shown in Appendix 3 may be used as a worksheet for the custodian to carry out the "Wipe Test". Results of a typical experiment are also entered for teachers' reference.

### **(D) Irregularity**

In case there is any irregularity found in the routine checks or any sealed source identified as defective, the paragraphs 2.5, 5.1 and 5.2 of the code of practice (reproduced below) should be referred.

- 2.5 All sealed sources failing the routine checks should be considered as defective and withdrawn from use.
- 5.1 Retention of defective, obsolete or unnecessary sources of radiation is undesirable and positive steps should be taken for the safe disposal of such sources. Such sources should either be returned to the supplier and the Radiation Board notified; or be disposed of in a manner approved by the Radiation Board.
- 5.2 In the event of damage to, or loss of any sources, the Physicist on-duty, Department of Health (Tel: 7110 3382 call 1912) and the Senior Occupational Health Officer, Labour Department (Tel: 2852 4045) should be notified immediately.

**(E) Radioactive source record**

A blank form on "Sealed Radioactive Source Record"(Appendix 4) is included for schools to make photocopies for their own use. A sample record of a typical source is also attached for teachers' reference. It is essential for each individual sealed radioactive source to have its own record.

**(F) Logbook**

All the results of the routine checks shall be entered into a logbook which shall be made available for inspection by the Radiation Board on request.

**(G) Storage cupboard**

It was stipulated in the Code of Practice that all sealed sources shall be kept in a locked metal container with an appropriate warning label outside. The purpose of the container is to prevent unauthorized access to the radioactive sources and to avoid dispersion of the radioactive materials in case of fire. It is therefore desirable that all radioactive materials should be stored in the metal container. The description of the metal storage cupboard suitable for this purpose, which has been included in the *List of Standard Furniture & Equipment for Physics (HKCE Level)* and is available from usual scientific equipment suppliers, can be found in Appendix 5. As the sealed sources are pointed downwards during storage, it is recommended that the cupboard be sited close to the floor.

**(H) Radioactive source lifting tool**

The spring holder type radioactive source lifting tool is recommended for extracting the sealed sources by the stem (4 mm diameter) and for holding the sources during some experiments. The descriptions of the tool can be found in Appendix 6. In some cases, the lifting tools were delivered to the school without the wire loop holding the two arms together which renders the spring action not operative. This can be easily remedied by the addition of a thin metal wire loop at the position indicated in the diagram in Appendix 6.

## Appendix 1

### Code of Practice on the Use of Radioactive Sources for Teaching Purposes in Schools

The use of radioactive sources for teaching purposes in schools is governed by the *Code of Practice on the Use of Radioactive Sources for Teaching Purposes in Schools* which was issued by the Radiation Board. The Code of Practice is reproduced below for reference.

#### 1. General Rules

1. Students should not be exposed to ionizing radiation unless there is a valid reason for doing so: demonstrations and experiments that result in exposure should be relevant to the course of instruction.
2. The use of sealed radioactive sources in schools shall be solely for the performance of simple experiments to demonstrate fundamental principles, and the sources used and the methods of using such sources shall be such as to ensure that the degree of risk is very small.
3. No demonstrations or experiments involving the deliberate exposure of students, staff or any other persons to ionizing radiation shall be performed.
4. Experiments should be carefully planned to minimise the exposure time, and preliminary rehearsals of the experiment procedure using simulated sources should be encouraged.

#### 2. Control of Sources

1. The Radiation Board is the statutory body which controls the use and/or possession of radioactive substance and irradiating apparatus in Hong Kong. Schools may be exempted from the requirement of applying for a licence if the total quantity of radioactive substances to be possessed and used by the individual schools does not exceed the limit specified in Section 21.3. Schools wishing to avail themselves of the opportunities to use radioactive sources should apply to the Secretary, Radiation Board, Department of Health (3/F., Sai Wan Ho Health Centre, 28 Tai Hong Street, Sai Wan Ho, Hong Kong) for exemption from obtaining a radioactive substance licence.
2. It shall be the responsibility of a graduate science teacher, who shall be designated the source custodian, to supervise the use of sealed radioactive sources within the school. Should the source custodian leave the school for any reason, a fresh application for exemption will have to be made in respect of the newly appointed source custodian.
3. The source custodian shall be responsible for the procurement, storage, issue and return of sources, the correct use of all sealed sources and the disposal of radioactive waste.
4. The source custodian shall arrange for routine checks, at intervals not exceeding 6 months, of the efficiency and condition of monitoring instruments and all sealed sources by wipe test (The source is wiped with a swab or tissue,

moistened with ethanol or water; the activity removed is measured. Acceptance limit : 200 Bq). All the results shall be entered into a logbook which shall be made available for inspection by any Radiation Board Inspector on request.

5. All sealed sources failing the routine checks should be treated as defective and withdrawn from use until proved otherwise.
6. The teacher in charge of a class shall account for all sealed sources before the period of instruction is concluded.
7. Sealed sources shall be used by a student only when under the direct personal supervision of a teacher.
8. The immediate responsibility of radiation safety in any experiment involving ionizing radiation shall rest with the teacher in charge.

### 3. Storage and Labelling

1. Maximum amount in store:

The activity of individual sealed sources kept in a school laboratory should be the minimum practicable and shall in all cases be no greater than the following exemption limit:

<b>Sealed sources</b>	<b>Quantity</b>
Cobalt-60, Strontium-90, Radium-226, Americium-241	<ul style="list-style-type: none"> <li>◆ Not more than two sources for each type</li> <li>◆ Each source less than 200 kBq</li> </ul>
Insoluble radium-226 sources of activity less than 750 Bq to be used with diffusion cloud chamber	<ul style="list-style-type: none"> <li>◆ Not more than 10 sources</li> <li>◆ Totally not more than 7.5 kBq in 10 sources</li> </ul>

**Remarks:** Should a school wish to use other sources or radioactive substances not in the Physics Standard Equipment and Furniture Lists, the Physicist on-duty of the Radiation Health Unit, Department of Health should be consulted (Tel: 2977 1868).

2. All sealed sources shall be kept in a locked metal container.
3. Access to this container shall be limited to authorised member of the school staff.
4. The metal container shall be permanently labelled (see Appendix V) with a warning sign to indicate that it contains radioactive substances.
5. Individual sources shall be stored in separate, appropriately labelled, containers or compartments within the locked metal container.
6. Each source shall be easily identifiable by the user.
7. Sealed radioactive sources and their containers shall be permanently labelled with the type of radionuclide together with the activity at specified date.

#### 4. Handling of Sources

Sealed radioactive sources shall be handled with care and unnecessary handling of sources should be avoided. The following rules shall apply :



1. Sources shall be transported between the laboratory and their place of storage in their containers.
2. **Radioactive sources shall only be handled by tongs or forceps.** Teachers should note that specially designed tongs for the safe handling of sources are available from commercial suppliers.
3. Sealed  $\alpha$ -emitting radioactive sources shall be handled with extreme care because of the necessarily fragile nature of their construction.
4. Sealed sources should whenever possible be kept at a distance greater than 30 cm from the user and any other persons in the vicinity, and should be pointed away from the human body.

#### 5. Damage to, Loss of and Disposal of Sources

1. Retention of defective, obsolete or unnecessary radioactive sources is undesirable and positive steps should be taken for the safe disposal of such sources. They should either be returned to the suppliers and the Radiation Board being notified; or be disposed of in a manner approved by the Radiation Board.
2. In the event of damage to, or loss of any sources, the following shall be notified immediately :

Physicist on-duty, Department of Health (Tel: 7110 3382 call 1912) and  
the Senior Occupational Health Officer, Labour Department  
(Tel: 2852 4045)

In all cases, the Secretary of Radiation Board shall be notified in writing within 48 hours.

#### 6. Health Risk

When due consideration is given to the limitation on the type of source, the activity of radioactive substances to be used in schools, and the time in any one year such sources will be used by any one teacher or student, the health risk from exposure to ionizing radiation to both teachers and students is extremely small. However, it is essential that students appreciate the nature of the hazard and the degree of care considered necessary in the handling of radioactive substances.

**APPLICATION FOR EXEMPTION FROM REQUIRING RADIOACTIVE SUBSTANCES LICENCE**  
**Use of Radioactive <sup>(1)</sup> Sources for Teaching Purposes in Schools**

1. Name of School/College \_\_\_\_\_  
 Address \_\_\_\_\_  
 Telephone Number \_\_\_\_\_ Fax Number \_\_\_\_\_ e-mail \_\_\_\_\_

2. Name and qualification of teacher who is designated as source custodian <sup>(2)</sup> .

Name	Degree(s) Obtained and Major Subjects	Awarding Institution	Year
Mr./Mrs./Ms./Miss*			

If the proposee has a degree majoring in physics, skip the following part and continue with part 3.

Does the proposee have 2 years experience in teaching higher form physics (e.g. Secondary 4-7)?

Yes  No

Has the proposee attended any radiation protection course recognised by Radiation Board?

Yes  No  If Yes, please state the course title and organising body.

3. Details of radioactive sources <sup>(3)</sup> to be used in the school.

Manufacturer/ Catalogue Number	Source	Activity/Unit	Maximum Exempt Quantity

4. The type of monitoring instrument <sup>(4)</sup> acquired/already\* put on firm order for purchase:

I hereby apply for exemption from requiring radioactive substances licence under the Radiation Ordinance. I declare that the above source(s) is/are\* for teaching purposes and that the instruction in the "Code of Practice on the Use of Sealed/Unsealed Radioactive Sources for Teaching Purposes in Schools" will be complied with.

Date \_\_\_\_\_

Signed \_\_\_\_\_  
 ( \_\_\_\_\_ )  
 Principal

School Chop \_\_\_\_\_  
 \*Delete as appropriate

Please see Guidance Notes at back page



## Guidance Notes

- (1) The Radiation Ordinance defines "Radioactive substances" as any substance which consists of or contains any radioactive chemical element whether natural or artificial and whose specific activity exceeds 75 becquerels of parent radioactive chemical element per gram of substance.
- (2) The source custodian shall be responsible for the supervision of the use of radioactive substances within the school. He/She should have a recognised degree with either one of the following conditions :
  - (a) Physics major
  - (b) At least two years teaching experience in higher form Physics (Secondary 4-7)
  - (c) Certificate on radiation protection recognised by the Radiation Board
- (3) The activity of individual sealed sources kept in a school laboratory should be the minimum practicable and shall in all cases be no greater than the following exemption limit.

Sealed sources	Quantity
Americium-241, Cobalt-60, Radium 226, Strontium-90	<ul style="list-style-type: none"><li>◆ Not more than two sources for each type</li><li>◆ less than 200 kBq for each source</li></ul>
Insoluble radium-226 sources of activity less than 750 Bq to be used with diffusion cloud chamber	<ul style="list-style-type: none"><li>◆ Not more than 10 sources</li><li>◆ Not more than 7.5 kBq in 10 sources</li></ul>

Schools may refer to the Standard Equipment and Furniture List for Physics (Secondary 4 and 5) revised in 2000 from the Education Department for reference.

- (4) A portable monitoring instrument capable of measuring beta and gamma radiation is normally enough e.g. a system with a G-M thin end window tube. However, for radium source of activity less than 750Bq to be used with diffusion cloud chamber, monitoring instrument is not required.
- (5) On completion, the form should be sent to the Secretary of the Radiation Board, Radiation Health Unit, Department of Health, 3/F., Sai Wan Ho Health Centre, 28 Tai Hong Street, Sai Wan Ho, Hong Kong.

## Appendix 2

**Purpose** : To check the efficiency and condition of the GM tube and scaler.

**Apparatus** : GM tube supported on its holder

Scaler

Source lifting tool

Support for source

Radioactive source (200 kBq Ra-226 or 200 kBq Sr-90)

**Procedure** :




Figure 2.1

1. Set up the apparatus as shown in figure 2.1. The distance between the source and the GM tube should be about 10-12 cm. Make sure that the radioactive source is pointing along the axis of the GM tube.
2. Switch on the scaler and allow five minutes to warm up.
3. Gradually increase the E.H.T. supply from above 300 V to the point at which the scaler starts to register counts. Record the applied voltage and the number of counts over 100 s. Calculate the count-rate.
4. Increase the voltage in steps of 20 V (or a convenient value). Record the applied voltage and counts. Calculate the count-rate each time and continue up to about 500 V.

**Results :**

Source used :  
 Distance : \_\_\_\_\_ cm

1. Complete the following table :

Applied Voltage/V									
Counts in 100 s									
Count-rate /s <sup>-1</sup>									

2. Plot a graph of count-rate against applied voltage. The graph should show a plateau (figure 2.2) with threshold voltage  $V_T$  at about 400 V and plateau length  $V_L$  of about 100 V.




Figure 2.2

Above the threshold voltage, further increments in applied voltage cause only small increases in the count-rate and this region is called the Geiger plateau (plateau region).

3. The working voltage  $V_w$  may be taken as  $V_T + 50$  V, i.e. about 450 V.

$$V_w = ( \text{_____} + 50 ) \text{ V} = \text{_____} \text{ V}$$

4. The plateau slope may also be found by following the procedures :

Choose two points  $(V_1, C_1)$  and  $(V_2, C_2)$  on the plateau.

Applied voltage :  $V_1 = \text{_____}$  V                       $V_2 = \text{_____}$  V

Corresponding Count-rate :  $C_1 = \text{_____}$  s<sup>-1</sup>                       $C_2 = \text{_____}$  s<sup>-1</sup>

Mean count-rate :  $C_0 = \frac{1}{2}(C_1 + C_2) = \text{_____}$  s<sup>-1</sup>

Plateau slope : % slope =  $\frac{C_2 - C_1}{V_2 - V_1} \times \frac{100\%}{C_0}$

$$= \text{_____} \% \text{ V}^{-1}$$

Remark : I. The Plateau slope should not be more than 0.2 % V<sup>-1</sup>

II. All values shown above are only characteristics of the GM tube, Mullard type ZP 1481 (MX 168). For other types of GM tubes, the relevant technical data should be referred.

Results :

SAMPLE

Source used : Sr 90  
 Distance : 11 cm

1. Complete the following table :

Applied Voltage/V	380	400	410	420	440	460	480	500	520
Counts in 100 s	7284	11258	12114	12430	12800	13254	13462	13813	14097
Count-rate/s	72.8	112.6	121.1	124.3	128.0	132.5	134.6	138.1	141.0

2. Plot a graph of count-rate against applied voltage. The graph should show a plateau (figure 2.2) with threshold voltage  $V_T$  at about 400 V and plateau length  $V_L$  of about 100 V.




Figure 2.2

Above the threshold voltage, further increments in applied voltage cause only small increases in the count-rate and this region is called the Geiger plateau (plateau region).

3. The working voltage  $V_w$  may be taken as  $V_T + 50$  V, i.e. about 450 V.

$$V_w = ( \underline{410} + 50 ) \text{ V} = \underline{460} \text{ V}$$


4. The plateau slope may also be found by following the procedures :

Choose two points  $(V_1, C_1)$  and  $(V_2, C_2)$  on the plateau.

$$\begin{aligned}
 \text{Applied voltage} & : V_1 = \underline{420} \text{ V} & V_2 = \underline{520} \text{ V} \\
 \text{Corresponding Count-rate} & : C_1 = \underline{124.3} \text{ s}^{-1} & C_2 = \underline{141.0} \text{ s}^{-1} \\
 \text{Mean count-rate} & : C_0 = \frac{1}{2}(C_1 + C_2) = \underline{132.65} \text{ s}^{-1} \\
 \text{Plateau slope} & : \% \text{ slope} = \frac{C_2 - C_1}{V_2 - V_1} \times \frac{100\%}{C_0} \\
 & = \underline{0.126} \% \text{ V}
 \end{aligned}$$

Remark : I. The Plateau slope should not be more than  $0.2\% \text{ V}^{-1}$

II. All values shown above are only characteristics of the GM tube, Mullard type ZP 1481 (MX 168). For other types of GM tubes, the relevant technical data should be referred.

Graph of Count-rate against Applied voltagesource : Sr 90distance : 11 cm

## Appendix 3

**Purpose** : To check for leakage or surface contamination of sealed radioactive sources by the "Wipe Test".

**Apparatus** : GM tube supported on its holder

Scaler

Source lifting tool

Support for source

ALL sealed radioactive sources possessed by the school

Swab or tissue or cotton buds

Plastic Bags (food storage bags), at least four

**Procedure** :

1. Measurement of background count-rate




Figure 3.1

- (a) Set up the apparatus as shown in figure 3.1. Make sure that there is not any radioactive material in the vicinity of 1 m from the GM tube.
- (b) Switch on the scaler and allow five minutes to warm up.
- (c) Set the E.H.T. supply at the working voltage of the GM tube. Record the counts in a period of 10 minutes. Calculate the background count-rate.

2. Measurement of count-rate for the source




Figure 3.2

- (a) Set up the apparatus as shown in Figure 3.2. Make sure that the source is pointing along the axis of the GM tube. The source should be placed at a distance ( $d$ ) from the GM tube such that a count-rate of at least  $200 \text{ s}^{-1}$  is attained or such that the count-rate is as high as possible. For different sources, the following recommendations may be useful.

Source	Distance ( $d$ )	Remark
$\alpha$ source (e.g. Am-241 200 k/ 5 kBq)	As near as possible to the GM tube without touching the tube.	The plastic cap of the GM tube should be removed.
$\beta$ source (e.g. Sr-90 350 k/ 200 kBq)	8 - 12 cm	-
$\beta$ source (e.g. Sr-90 5 kBq)	1 - 3 cm	-
Source with $\beta$ radiation (e.g. Ra-226 200 kBq)	8 - 12 cm	-
Source with $\gamma$ radiation (e.g. Co-60 200 kBq)	1 - 3 cm	-

- (b) With all conditions of the GM tube and scaler remain unchanged as in step 1. Record the number of counts in 100 s. Calculate the count-rate. Repeat for at least three times and determine the mean count-rate and the actual count-rate (= mean count-rate - background count-rate).

3. Measurement of count-rate for the wiping material




Figure 3.3

- (a) Use a pair of tongs to grip a piece of cotton bud (available in supermarkets or drug stores), swab or tissue, moistened with ethanol or water, wipe the entire external surface of the sealed source carefully and lightly. Avoid dropping any liquid on to the bench top and avoid scratching the source surface. Pay special attention when wiping  $\alpha$  sources because of the fragile nature of their construction. Put the wiped source back to its storage box.
  - (b) Transfer the wiping material to the source lifting tool and set up the apparatus as shown in Figure 3.3. Make sure that the wiping material is at the same distance from the GM tube as in step 2 and the material is pointing along the axis of the GM tube. Also make sure that there is not any radioactive material in the vicinity of 1 m from the set-up.
  - (c) Record the number of counts in 10 minutes. Calculate the count-rate and determine the actual count-rate (= measured count-rate - background count-rate).
4. Put all wiping materials that are found to show no irregularities into double plastic bags which are to be sealed and disposed as usual garbage.
  5. Any wiping material showing irregularities should be placed in separate double plastic bags labelled with the tested sources, date and time of testing, and estimated radioactivity of the wiping material. The bags should be sealed and stored in the storage cupboard for further action.
  6. Update the "Sealed Radioactive Source Record".
  7. Repeat steps 1. to 6. for ALL sealed radioactive sources possessed by the school.



**Results :**

**1. Background count-rate**

Counts in 10 minutes period =

Background count rate =  $C_b = \text{_____ } s^{-1}$

The background count-rate should be about 0.5 - 1.0  $s^{-1}$ .

**2. Count-rates for the sources and the wiping materials**

Source								
Radioactivity /Bq								
Distance d /cm								
Counts in 100s for source								
Mean count-rate for source $C_m /s^{-1}$								
Actual count-rate for source $(C_s = C_m - C_b) /s^{-1}$								
Counts in 10 minutes for wiping material								
Count-rate for wiping material $C_c /s^{-1}$								
Actual count-rate for wiping material $(C_w = C_c - C_b) /s^{-1}$								

### 3. Activity of the wiping material

The activity of the wiping material may be estimated by assuming under the same experiment conditions, the actual count-rate is directly proportional to activity.

For :  $C_s$  = actual count-rate of the source

$C_w$  = actual count-rate of the wiping material

$A_s$  = activity of the source

$A_w$  = activity of the wiping material

$$\frac{A_s}{A_w} = \frac{C_s}{C_w}$$

$$A_w = A_s \times \frac{C_w}{C_s}$$

Complete the following table :


Source								
Activity of source $A_s$ /Bq								
Actual count-rate for source $C_s$ /s <sup>-1</sup>								
Actual count-rate for wiping material $C_w$ /s <sup>-1</sup>								
Activity of wiping material $A_w$ /Bq								
Result of "Wipe Test"								

The acceptance limit is 200 Bq. Mark the source in the table with an asterisk "\*" and label the storage box of the source that fails in the "Wipe Test".

#### Remarks

- I. Owing to the random nature of radioactivity, the actual count-rate of the wiping material may be negative. In this case, the activity of which may be considered to be negligible.
- II. If the "Wipe Test" is carried out in separate sessions, the background count-rate should be measured before each session.

- III. As the half life of the Co-60 source is only 5.27 years, this should be taken into account when calculating the radioactivity in the "Wipe Test". The source may be considered to have a radioactivity of 200 kBq at the date of delivery and the graph below may be used to estimate the radioactivity of this source at the time of the "Wipe Test".



An alternative way is to calculate the radioactivity of the Co-60 source using the formula below :

$$A_s = 200 e^{-\lambda t} \text{ kBq}$$

$$\text{where } \lambda = \frac{\ln 2}{5.27}$$

t = time in years since delivery of the source.

IV. The purpose of performing "Wipe Test" is to check whether the radioactive sources are leaking. It is therefore not always necessary to find out the actual radioactivities on the wiping materials. In that case, a more straight forward approach may be adopted. This is done by counting the individual wiping material for a period of 10 min. After which the number of counts is compared with that from background. If the difference exceeds 3 standard deviation (at 1% significant level) of background counts, then the source is suspected to be leaking. The table below would be used in place of the table in paragraph (3) for the results.

Background counts (N) for 10 min. =

Standard deviation of background counts ( $\sqrt{N}$ ) =

3 x (standard deviation) =

Source wiped								
Counts in 10 min. for wiping material								
Actual counts (= Measured counts - background counts)								
Actual counts > 3 standard deviation?								
Result of "Wipe Test"								

**NOTE :** In employing the method described on this page, the wiping materials need not be placed too far away and at various distances from the GM tube since comparisons with source activities are not necessary. In this case, all wiping materials can be placed at 0.1 - 0.5 cm from the detector such that detection sensitivity would be increased.

**Results :**

**1. Background count-rate**

Counts in 10 minutes period = 405

Background count rate  $C_b = \underline{0.675} \text{ s}^{-1}$

The background count-rate should be about  $0.5 - 1.0 \text{ s}^{-1}$  .

**2. Count-rates for the sources and the wiping materials**

Source	Ra-226	Am-241	Sr-90	Co-60	Sr-90	Am-241	Sr-90	Co-60
Radioactivity /Bq	200 k	200 k	200 k	200 k	350 k	5 k	5 k	200 k
Distance d /cm	10.5	0.1	8	1	6	0.1	2	1
Counts in 100s for source	23719	54543	22194	12601	23849	20093	7216	8943
	23513	55336	23098	12517	23767	19913	7288	9159
	23511	55093	21879	12502	23832	21485	7339	9053
Mean count-rate for source $C_m /s^{-1}$	235.8	548.9	223.9	125.4	238.2	205.0	72.8	90.5
Actual count-rate for source $C_s (= C_m - C_b) /s^{-1}$	235.1	549.2	223.2	124.7	237.5	204.3	72.1	89.8
Counts in 10 minutes for wiping material	395	390	402	437	387	374	388	386
Count-rate for wiping material $C_c /s^{-1}$	0.66	0.65	0.67	0.73	0.65	0.62	0.65	0.64
Actual count-rate for wiping material $(C_w = C_c - C_b) /s^{-1}$	Negl	Negl	Negl	0.05	Negl	Negl	Negl	Negl

### 3. Activity of the wiping material

The activity of the wiping material may be estimated by assuming under the same experiment conditions, the actual count-rate is directly proportional to activity.

For :  $C_s$  = actual count-rate of the source

$C_w$  = actual count-rate of the wiping material

$A_s$  = activity of the source

$A_w$  = activity of the wiping material

$$\frac{A_s}{A_w} = \frac{C_s}{C_w}$$

$$A_w = A_s \times \frac{C_w}{C_s}$$

Complete the following table :

Source	Ra-226	Am-241	Sr-90	Co-60	Sr-90	Am-241	Sr-90	Co-60
Activity of source $A_s$ /Bq	200 k	200 k	200 k	200 k	350 k	5 k	5 k	200 k
Actual count-rate for source $C_s$ /s <sup>-1</sup>	235.1	549.2	223.2	124.7	237.5	204.3	72.1	89.8
Actual count-rate for wiping material $C_w$ /s <sup>-1</sup>	Negl	Negl	Negl	0.05	Negl	Negl	Negl	Negl
Activity of wiping material $A_w$ /Bq	Negl	Negl	Negl	56.1	Negl	Negl	Negl	Negl
Result of "Wipe Test"	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.

*The acceptance limit is 200 Bq. Mark the source in the table with an asterisk "\*" and label the storage box of the source that fails in the "Wipe Test".*

#### Remarks

- I. Owing to the random nature of radioactivity, the actual count-rate of the wiping material may be negative. In this case, the activity of which may be considered to be negligible.
- II. If the "Wipe Test" is carried out in separate sessions, the background count-rate should be measured before each session.

IV. The purpose of performing "Wipe Tests" is to check whether the radioactive source are leaking. It is therefore not always necessary to find out the actual radioactivities on the wiping materials. In that case, a more straight forward approach may be adopted. This is done by counting the individual wiping material for a period of 10 min. After which the number of counts is compared with that from background. If the difference exceeds 3 standard deviation (at 1% significant level) of background counts, then the source is suspected to be leaking. The table below would be used in place of the table in paragraph 3 for the results.

Background counts (N) for 10 min. = 405

Standard deviation of background counts ( $\sqrt{N}$ ) = 20.1

3 x (standard deviation) = 60.3

Source wiped	Ra-226 200k	Am-241 200k	Sr-90 200k	Co-60 200k	Sr-90 350k	Am-241 5k	Sr-90 5k	Co-60 200k
Counts in 10 min. for wiping material	395	390	402	437	387	374	388	386
Actual counts (= Measured counts - background counts)	Negl	Negl	Negl	32	Negl	Negl	Negl	Negl
Actual counts > 3 standard deviation?	No	No	No	No	No	No	No	No
Result of "Wipe Test"	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.	O.K.

**NOTE :** In employing the method described on this page, the wiping materials need not be placed too far away and at various distances from the GM tube since comparisons with source activities are not necessary. In this case, all wiping materials can be placed at 0.1 - 0.5 cm from the detector such that detection sensitivity would be increased.

## Appendix 4

<b>Sealed Radioactive Source Record</b>		<b>Quantity</b>	<b>Nuclide</b>
<b>Supplier</b>	<b>Type No.</b>	<b>Activity</b>	<b>On (date)</b>
<b>Location</b>		<b>Responsible Person</b>	
		<b>Name</b>	<b>Signature</b>
<b>Description of source</b>			
<b>Description of container</b>			
<b>Drawings of source and container</b>			

Routine Check :

Date	Result of "Wipe Test"	Signature of Custodian	Remark



<b>Sealed Radioactive Source Record</b>		<b>Quantity</b> 1	<b>Nuclide</b> Americium - 241
<b>Supplier</b> Hong Kong Scientific Co.	<b>Type No.</b> Philip Harris Q87215/7	<b>Activity</b> 200 kBq	<b>On (date)</b> 1 Jan. 1999
<b>Location</b>  Cupboard B3, Preparation Room, Physics Laboratory.		<b>Responsible Person</b>	
		<b>Name</b> Mr. CHAN Tai-man	<b>Signature</b> TM Chan
<b>Description of source</b> Mainly an alpha emitter, may have some gamma emission but the highest energy is 60 keV		<u>Energies</u> : $\alpha = 5.44, 5.48 \text{ MeV}$ $\gamma = 0.026 - 0.060 \text{ MeV}$ <u>Colour code</u> : Brown	<u>Half-life</u> : 458 years
<b>Description of container</b> Sealed source in metal mounted with 4 mm stem, supplied in lead castle envelope in wooden box.			
<b>Drawings of source and container</b>			
<p style="text-align: center;">             Hardwood storage box (100 x 75 x 65 mm)              Lead castle with lid              Top View              Source              Brown         </p>			

Routine Check :


Date	Result of "Wipe Test"	Signature of Custodian	Remark

Sealed Radioactive Source Record		Quantity	5	Nuclide	Radium		
Supplier	Hong Kong Scientific Co.	Type No.	Philip Harris Q87600/9 Diffusion cloud chamber	Activity	< 750 Bq	On (date)	1 Jan. 1999
Location Cupboard C2, Preparation Room, Physics Laboratory.				Responsible Person			
				Name	Mr. CHAN Tai-man	Signature	T.M.Chan
Description of source The weak radioactive source (radium) gives mainly alpha and beta radiations.							
Description of container The source is mounted on the inside of the diffusion cloud chamber together with a pair of aluminium foil screen, which is approximately 0.025 mm and 0.18 mm thick respectively.							
Drawings of source and container							
Overall dimesnion : 105 mm diameter 90 mm height							

## Appendix 5

### Storage cupboard

A stoutly built enamelled sheet-steel cupboard having a louvred, lockable door bearing an appropriate warning plate. The rear wall of the cupboard carries two narrow steel shelves. A rectangular plastic tray is provided so that any spillages are contained and can be washed away easily. Dimensions 380 mm x 380 mm x 380 mm.



## Appendix 6

### Radioactive source lifting tool

For lifting sources and supporting them during use. Plated phosphor-bronze spring holder with jaws channelled longitudinally and transversely. Overall length 150 mm.

